

# Pally Magnum & Lid User Guide



## 1. Carrying the lid

The Half Euro Loadhog Lid is designed with integrated handles for ease of carrying / lifting and manoeuvring of the PallyMagnum when loaded



## 2. Installing the lid

Carry the lid using the ergonomic holds as shown above, position over the PallyMagnum and ensure the lid sits firmly over all corners of the unit. Lower until lid is securely in place



## 3. Attaching the strap

Take hold of hook and draw out sufficient strap to reach the Pally. Locate the hook on one side of the Pally pedal.



## 4. Tensioning the strap

The strap is tensioned by rotating the yellow lever to the left until the strap is sufficiently secure

Repeat this on the strap located on the other side of the Loadhog Lid

The Pallet should now be fully secure with both straps located and tensioned to the appropriate strength



## 5. To release the strap mechanism

Slide the green “RELEASE” button firmly to the left using your thumb until it engages

Rotate the yellow lever to the left until it stops. Then push the lever in one gentle movement further to the left – this will release the tension in the strap and the strap will be free to retract or extend

Pull a little strapping down (sufficient for the hook to be free from the Pally base). Gently guide the strap back into the lid as it retracts. Ensure the hook is fully located back in it's housing in the Lid to prevent damage

Repeat these steps on the other side of the lid. The load should be free for breaking down or picking at this point.



## 6. Removing and stacking the lid

Using the in-built hand holds, take hold of the lid with both hands and carefully lift off the lid

Stack the lid the correct way up on a spare PallyMagnum as shown above. The internal dimensions of the lid are designed to fit exactly on to the PallyMagnum (folded or Unfolded).

Nest other lids carefully and securely on top of the base lid up to a maximum of 20 lids per PallyMagnum.



# Pally Magnum

## Operating instructions

# 1. How to erect the Pally Magnum

Start by pulling into a vertical position the 2 long sides (800mm)

Repeat the operation on the other side, your Pally is fully erected

Pull one of the smaller side, making sure that it is completely locked with the vertical sides.



## 2. How to fold the Pally Magnum

Start to fold the PallyMagnum on one of the smaller sides (600mm). Pull the handle to unlock the first side and push it down

Repeat the operation on the other side.

Simply push the long sides, one after the other. Your PallyMagnum is now folded.



## 3. Change from Pallet to Dolly/ Dolly to Pallet

To change the PallyMagnum from Pallet mode to dolly mode, apply a **HALF** pressure on the pedal. This retracts the bearers and your Pally is now on Dolly form.



To change from Dolly to pallet, apply a **FULL** pressure on the pedal. This ejects the bearers and your Pally is now on pallet form.

The red sticker indicates that the Pally is in Pallet mode.



## 4. How to stack folded Pally Magnum

For this operation, 2 options are available: using a mechanical handling equipment / or manually.

### Using the Easy Lifter

You need to check that the Pally feet are engaged (Pallet position) and securely in position around the base of the next PallyMagnum.



**ALWAYS MAKE SURE  
THAT THE 4 CORNERS  
ARE SECURELY  
LOCKED IN PLACE**



## 4. How to stack folded Pally Magnum

### Carrying the unit manually

If you lift the unit, make sure that you are positioned on the short sides. You need to check that the Pally feet are engaged and securely in position around the base of the next PallyMagnum.



ALWAYS MAKE SURE  
THAT THE 4 CORNERS  
ARE SECURELY  
LOCKED IN PLACE

# X

DO NOT PICK THE PALLY  
MAGNUM ON YOUR OWN



## 5. How to Stack erected magnum

To stack erected Magnum, make sure that the lid is in place and securely installed.

Do not stack the Pally Magnum on top of another Pally Magnum without the Lid.

Make sure that the PallyMagnum is in "pallet Form" (bearers out)

When dropping the PallyMagnum, it must engage with the up stands that are located on top of the lid.



Make sure that you strap the 2 units using the straps from the top lid. This is very important to insure perfect stability. The 2 units are now safe to be moved either with a fork lift or manually.

